



## Trail Tent 4 & 6-Pitching Instructions

In order to familiarize yourself with your new tent, we recommend you "test pitch" it before embarking on your wilderness adventure.

Package Includes: Tent Body, Rain Fly, 2 long multi-diameter fiberglass poles, 2 short ridge pole, Guy Cords, Ground Stakes, 1 Pole Sack and 1 Stake Sack.



Step 1: Find an even piece of ground, stake out your tent. Carefully assemble the poles. Position poles in X over the tent. For Trail Tent 6, slide the poles through the pole sleeves.



Step 2: Insert pole tip of pole into the grommet on the stake loop do this for each pole. Gently arch the pole and insert opposite pole tip in grommet on other side of tent.



Tent body clip, attached to pole



Ridge pole grommet attachment



Grommet Pole attachment and Rain Fly Attachment



Step 3: Starting at the center of the tent, connect the center clip to the pole. Then work your way around the tent securing the all clips to the tent poles. Attach ridge poles over main poles and insert tips into the grommets above the tent door.



Step 4: Lay fly over tent. Secure the rain fly to tent by connecting the side release buckle to their mates on each corner. Stake out the vestibules, add guylines as needed and admire your new tent.