




# SLUMBER SHACK 4

Please familiarize yourself with this tent and its set-up procedures before first use. It's best to use 2 (or more) people and SJK recommends that all users practice "test pitching" this tent several times before venturing into the wild. Please note, the attached tarp can be configured in many ways, with or without a vehicle, be creative. Package Includes: Main tent body with attached tarp, 2 "Y" Shaped Molded Hubs, 2 steel support poles, 2 long fiberglass poles, 1 aluminum pole, 1 short fiberglass pole (back), 10 stakes & carry bags. For additional information please visit [www.SJKgear.com](http://www.SJKgear.com) or call 1 (800) 233-6283



**Set Up** - 1) Spread out main tent body and tarp in correct orientation to your desired camp site. 2) Stake out back of tent in order to help with initial set-up. 3) Moving to the front of the tent, insert both capped ends of the long long fiberglass poles into the pole sleeves until they end in the webbing buckets at the back corners of the tent. 4) Next, fully insert the short aluminum brow pole into the pole sleeve above the main door and resting on top of the long fiberglass poles. 5) Find the "Y" shaped hubs (at the front/top corners of the tent) and under tension, insert the two steel support poles first, then the two fiberglass poles and lastly, insert the smaller aluminum brow pole into the hubs. 6) Insert the ends of the steel support poles into the metal pins at the bottom/front corners of the tent and attached the molded clips to the steel support poles on both sides. 7) Moving to the back of the tent, slide the short fiberglass pole through the back pole sleeve and insert the pole ends into the molded buckets. 8) For improved ventilation inside tent, prop open the top vent using the integrated support tab. 9) To finish setting up the main tent body, attach molded clips to the steel support poles running down the front sides of the tent. 10) Before fully staking out tent, determine how you would like to utilize the integrated 3-in-1 tarp (attached to a vehicle, lean-to or with accessory poles). 11) Lastly, stake out all guy line points to improve structural integrity in bad weather.

**Wheel connection straps:** 1) Park vehicle on flat ground, place vehicle in park, engage parking brake & kill engine. 2) **Allow brakes to fully cool before proceeding.** 3) Drape short end of the tarp over the rear of vehicle, extend wheel straps down to rear wheels & loop around one wheel "spoke" and tighten as needed. 4) Use the center seam on tarp as a guide to center the tarp on vehicle and adjust straps as needed. Do not over tighten, just snug them up. 5) Note\* Do not move vehicle while wheel straps are attached.

**General comments / Tips:** **Pole set up:** During set up, ensure that each pole segment is fully seated into the adjoining pole segment, failure to do so will damage the poles. **Guy line tips:** When setting up the guy lines, tie knot with a small fixed loop directly to the webbing loops on the tarp & main tent body. It's best to wrap the triangle fabric flap around the back fiberglass tent poles and then guy out for additional structural support. Guy lines will need to be adjusted on the tarp & tent as needed for different configurations. **Supplemental attachment loops:** This tarp has three extra webbing loops with side release buckles on the vehicle end of the tarp. These loops are not necessary for the configurations described above. They are provided to encourage creativity & accomodate alternate configurations.

**\*\*Disclaimer:** Dirt and grit on your vehicle may rub against the tarp and impact your vehicle's finish, be aware and act accordingly. Slumberjack will not be held liable for any damage to your vehicle. Please note, configurations shown above may not fit all vehicles. All questions are welcome & thank you for your business!

# SJK / Slumberjack Tent User Manual

## DANGER



### DO NOT USE FUEL-BURNING DEVICES INSIDE OR NEAR THIS TENT.

Stoves, lanterns, candles, grills, heaters and other fuel burning devices produce carbon monoxide and will consume the available oxygen in this tent.

**FAILURE TO FOLLOW THESE WARNINGS  
WILL CAUSE ASPHYXIATION, CARBON  
MONOXIDE POISONING, AND DEATH OR  
SERIOUS AND PERMANENT INJURIES**

## WARNING



### KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.

This tent is made with flame resistant fabric which meets CPAI-84 specifications. IT IS NOT FIREPROOF. The fabric will burn if left in continuous contact with any flame source.

The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective. This tent must be properly ventilated in all weather conditions. For example, snow could obstruct airflow and cause asphyxiation unless cleared frequently.

NEVER leave children unattended inside a tent. Anchor your tent securely to provide additional security from changing climatic conditions. Snow pegs, skis and/or heavy rocks may be necessary to supplement tent stakes and guy cords.

**FAILURE TO FOLLOW THESE WARNINGS COULD CAUSE ASPHYXIATION, CARBON  
MONOXIDE POISONING, AND DEATH OR SERIOUS AND PERMANENT INJURIES.**

### COPING WITH THE UNEXPECTED

Even though SJK / Slumberjack uses only the best quality materials, accidents and normal wear and tear do take their toll on your tent.

#### Poles

Before pitching your tent, be sure all sections of your poles are fully engaged at their joints. Gaps at section joints will expose the pole's inserts to forces for which they were not intended. This can cause them to bend or break. Tent pole inserts are sufficiently strong for their function, but only when they are fully joined and connected with their mating tube sections.

While assembling or folding your poles, be sure not to allow pole sections to snap against one another as the impact can cause stress fractures and denting of the tube ends. Try to avoid stepping on or striking your poles on rocks during setup. Pole damage most frequently occurs during pitching, or when horseplay occurs around the tent. Be sure not to bend your poles into tighter curves than they naturally assume in the tent – take extra caution in high wind situations. Excessive bending or distortion of the poles can occur in a free-standing tent if it is picked up by only one of its poles while moving the tent. Move a free-standing tent by grasping it at the pole intersections. A slightly bent pole does not lose its strength and does not require replacement unless it distorts the shape of the tent.

Proper care of poles includes keeping them clean and free of dirt and salt.

Always rinse poles with fresh water if exposed to salt water or after coastal camping. Occasional lubrication of the section joints with silicone spray will help the joints slide together freely and will help keep ice from forming, and causing problems in snow.

#### Shockcord

Your SJK / Slumberjack poles are assembled with extreme weather shockcord – the only elastic cord created especially to withstand the rigors of serious backpacking and mountaineering use. Keeping your poles in a fully (or partially) extended position during long-term storage will relieve the tension on the elastic cord and help to ensure maximum performance and reliability. When folding your poles, be sure to fold from the center out so as not to place uneven tension on the elastic cord.

Occasionally the shockcord in your poles may break, pull out of the pole, or just go limp. This is not a disaster; the pole is still perfectly functional. The tension on the pole when it is set in place on the tent will keep it together. Finish your trip and return the pole to the SJK / Slumberjack Warranty Department, at your leisure, for repair.

#### Zippers

Always be gentle when operating zippers. Avoid standing on them and try to limit exposing them to dirt and grit. Taking these precautions combined with frequent cleaning will protect them against premature failure.

#### Tears and Damage

Despite your best efforts, sometimes damage does occur to your tent. Waterproof self-adhesive repair tape is sold at many outdoor stores and several pieces can be tucked into the tent bag without adding any appreciable weight. Urethane based seam sealing products can be used to plug small holes. Low residue duct tape works as well for minor field repair. It's a good idea to carry one or a combination of these things with your tent in the event the tent is damaged while in use. Duct tape should be removed at end of trip.

#### Condensation

Condensation is the build-up of moisture on the inside of your rainfly and tent walls due to a temperature difference between the inside and outside of your tent. Condensation occurs mostly when the conditions are cold, rainy, or humid, although it can occur at any time. The best way to minimize condensation is to increase the ventilation within your tent and between the tent body and fly. Completely guying out the rainfly often helps, as does leaving the vestibule door open as much as possible.

### HOW TO CARE FOR YOUR TENT

#### Before You Go Camping: Weatherproofing Your Tent

Additional seam sealing can be added to the perimeter to further insure waterproofness. The rainfly and center floor seam (if applicable) of your tent have been taped at the factory. While seam tape significantly increases the weatherproofness of your tent, additional seam sealing will improve the performance of your tent in rainy conditions. For additional weatherproofness, seal all places where attachments are sewn to the fly, including webbing, Velcro, snaps, guy-outs, and zipper tracks. The best way to seal your tent is to use a urethane-based seam sealer and run a thin bead around the base of the attachment, where it is sewn to the tent.

#### Caring for Your Tent on the Trail

It is important to select a site which has been cleared of any sharp objects such as rocks or sticks. Many people prefer to use ground sheets under the tent for additional protection. If you choose to do so, make sure the floor of the tent completely covers the ground sheet, or else the sheet will collect rain. Tent Footprints are now available for all current SJK / Slumberjack tents.

#### Staking and Guying Out Your Tent

Most SJK / Slumberjack tents are free-standing, not requiring the use of stakes in order to pitch the tent. This is a matter of convenience, allowing quick set-up and easy moving and cleaning of the tent. All tents, free-standing or not, must be staked out properly in order to achieve full structural integrity and prevent wind damage. No lightweight, back-packing style tent, whether rated at 3-season or 4-season, is capable of withstanding strong, wind gusts, without damage unless anchored and guyed properly. Guying out your tent can increase rain protection and ventilation and greatly enhance wind resistance.

#### Fire

Your tent is constructed of flame-retardant materials, however this material will melt if exposed to sufficient heat or open flame. Use prudence in positioning your tent near campfires, stoves, barbecues, etc.

#### Caution:

SJK / Slumberjack is absolutely against cooking inside a tent. Asphyxiation, severe or even fatal burns are possible if a stove is used in a tent, or vestibule, without adequate ventilation. Additionally, a hot stove can melt through your tent floor if the stove is not rigorously insulated; and pots of hot liquid, if left uncovered, may create a condensation ridden tent.

#### Ultraviolet Light

UV light is one of the most damaging of all the elements. When exposed to prolonged and extensive sunlight most fabrics will fade, lose strength, and eventually break down. Try to minimize exposing your tent to the sun. Store it during the day or pitch it in shady areas.

#### Animal Hazards

Animal damage to tents is all too common, but is usually easily avoidable: Never store food in your tent!

#### What to Do When the Trip is Over

It is important to dry your tent completely before returning it to its stuff sack. If stored wet, mildew will occur. Mildew damage is not covered under warranty. In needed gently hand wash your tent with a mild soap and a sponge. Do not use harsh detergents, chemicals, or abrasive materials. Dirt particles left in the weave of the material speed up the deterioration of the fabric. Clean tents last longer. Never machine-wash your tent!! Over extended periods, store your tent loosely, out of the bag in a cool, dry environment.

### SJK / Slumberjack Warranty and Repair Service

We maintain a full repair facility to assist you with any problems you may have with any SJK / Slumberjack product. We offer a lifetime warranty against defects in materials and workmanship, and for a nominal charge we will repair damage due to accidents or normal wear and tear. This warranty does not cover damages caused by improper care, accidents, or the natural breakdown of materials over extended use and time. All items returned for repair must be clean. SJK / Slumberjack does not wash tents! Dirty tents will be returned to sender for cleaning. Please contact customer service with comments or questions at [hunt@slumberjack.com](mailto:hunt@slumberjack.com) by calling 800-233-6283 during regular business hours.